



# Data Sheet

Form No.	Issue Date	Rev. Date
DS-4024	06/15/17	5/21/18

## Eclipse GEN 2.0 Foam Generators:

### Specify Eclipse GEN 2.0 Foam Generators as follows:

**Voltage:**

12 or 24

**Controller (HMI):**

Single Tellurus Panel

Dual Tellurus Panel

**HMI Settings:**

Default (*English*)

**Number of Generators:**

Two

Three

**Generator Valve Type:**

Elkhart

**Generator Outlet Connection:**

External 2 in. Victaulic with 1-1/2 in. FNPT internal threads

**Generator 1 Hose Size:**

*(Hose size/panel connection to be used with Generator 1)*

1.00 in. / 25 mm

1.50 in. / 38 mm

1.75 in. / 45 mm

2.00 in. / 50 mm

2.50 in. / 64 mm

**Generator 2 Hose Size:**

*(Hose size/panel connection to be used with Generator 2)*

1.00 in. / 25 mm

1.50 in. / 38 mm

1.75 in. / 45 mm

2.00 in. / 50 mm

2.50 in. / 64 mm

**Generator 3 Hose Size:**

*(Hose size/panel connection to be used with Generator 2)*

*(Applicable only if Three Generators are ordered)*

1.00 in. / 25 mm

1.50 in. / 38 mm

1.75 in. / 45 mm

2.00 in. / 50 mm

2.50 in. / 64 mm

High Rise (*Only selection if High Rise option is ordered*)

High Flow (*Only selection if High Flow option is ordered*)

## The Following Items are Optional:

### **High Rise Option:**

*(Requires Three Generators to be ordered)*

*(Generator 3 operates at a higher discharge pressure)*

Not Required *(Standard)*

With *(Optional)*

### **High Flow Option:**

*(Requires Three Generators to be ordered)*

*(Generator 3 flows at a higher capacity)*

Not Required *(Standard)*

With *(Optional)*

### **Discharge Splitting Valve Option:**

*(Directs a single generator discharge to two locations)*

Not Required *(Standard)*

With *(Optional)*