

Document Number	Issue Date	Rev. Date
SPL81614	11/88	7/9/19


### Medium Duty K Transmission Service Parts List

Pump					;	See Page			
Model (Located on Serial Plate)			Transmission Input Shaft				Transmission Case		
Main Pump		Combination Pump	Туре	1-1/8 in. Keyed	Hydraulic Pump Adapter	Splined	Optional Tachometer	Mounting to Pump	Mounting Positions
			Non-Extended Impeller Shaft	2, 3	4, 5				
CLVK, CI			Extended Impeller Shaft for Driving a Compressor	6, 7	8, 9				
			Non-Extended Impeller Shaft	2, 3	4, 5		14, 15		
CPK-1, C	CPK-2	-	Extended Impeller Shaft for Driving a Compressor	6, 7	8, 9	-			
	Pumps Built Prior to December 1, 1990	-	Non-Extended Impeller Shaft	2, 3	-				
CPK-3	Pumps Built After December 1, 1990	-	Non-Extended Impeller Shaft	10, 11	-				
CPK-4		-	Non-Extended Impeller Shaft	2, 3	-				
CMYB, CMYC, CMYD, CMYE, CMYF CMYBX, CMYCX, CMYDX, CMYEX, CMYFX CMUYB, CMUYC, CMUYD, CMUYE, CMUYF CMUYBX, CMUYCX, CMUYDX, CMUYEX, CMUYFX  CMC10B, CMC10C, CMC10D, CMC10E, CMC10F CMUC10B, CMUC10C, CMUC10D, CMUC10E, CMUC10F  CMC20B, CMC20C, CMC20D, CMC20E, CMC20F CMUC20B, CMUC20C, CMUC20D, CMUC20E, CMUC20F  CMPA, CMUPA  CSYB, CSYC, CSYD, CSYE, CSYF CSYBX, CSYCX, CSYDX, CSYEX, CSYFX		CPK-1, CPK-2	Combination Pump CPK-1 or CPK-2 is mounted on the Rear of the Main Pump Transmission and acts as an Ex-	-	-	12, 13	-	14, 15	16, 17
CSUYB, CSUYC, CSUYD, CSUYE, CSUYF CSUYBX, CSUYCX, CSUYDX, CSUYEX, CSUYFX CSC10B, CSC10C, CSC10D, CSC10E, CSC10F CSUC10B, CSUC10C, CSUC10D, CSUC10E, CSUC10F		-	tra Pressure Stage						
CSC20B, CSC20C, CSC20D, CSC20E, CSC20F CSUC20B, CSUC20C, CSUC20D, CSUC20E, CSUC20F		]							
CSPA, CSUPA									
CGGWB, CGGWBX									

### Non-Extended Impeller Shaft 1-1/8 in. Keyed Input Shaft Models: CLVK, CLRK, CLSK, CPK-1, CPK-2, CPK-3, CPK-4

REF. NO.	DESCRIPTION
T1	Woodruff Key
T2	Serial Plate (CPK-1, CPK-2, CPK-3, CPK-4 Models Only)
Т3	Driven Gear
T4	Gasket
Т6	Gasket
T8	Gasket
Т9	Bearing Cover
T10	Oil Seal Housing
T11	Drive Shaft
T13	Gear Case Subassembly
T14	Dowel Pin, 3/8 x 1 in.
T15	Drive Gear
T17	Breather, 1/2 NPT
T18	Magnetic Drain Plug, 1/2 NPT
T19	Hex Hd Screw, 3/8-16 x 1-1/4 in.
T24	Oil Seal

REF. NO.	DESCRIPTION
T25	Lockwasher, 3/8 in.
T28	Retaining Ring
T31	Pipe Plug, 1/2 NPT
T32	Drive Screw, No. 6 x 1/4 in.
T33	Ball Bearing
T34	Ball Bearing
T50	Oil Seal
T67	Oil Level Plate
T69	Street Elbow, 45 Degree x 1/2 NPT
T75	Bearing Spacer
T76	Square Key
T77	Castle Nut or Nylok Nut
T79	Flat Washer, 3/4 in.
T80	Cotter Pin, 1/8 x 1-1/2 in.
T92	Hex Head Screw, 3/8-16 x 1 in.




- 1. SHOWN WITHOUT TACHOMETER DRIVE. SEE PAGE 15 FOR OPTIONAL TACHOMETER.
- 2. SERIAL PLATE INSTALLED ON PUMP VOLUTE BODY FOR CLVK, CLRK AND CLSK MODELS.

#### Non-Extended Impeller Shaft Hydraulic Pump Adapter Input Shaft Models: CLVK, CLRK, CLSK, CPK-1, CPK-2

REF. NO.	DESCRIPTION
T1	Woodruff Key
T2	Serial Plate (CPK-1, CPK-2 Models Only)
Т3	Driven Gear
T4	Gasket
T6	Gasket
T8	Gasket
Т9	Bearing Cover
T10	Oil Seal Housing
T11	Drive Shaft
T13	Gear Case Subassembly
T14	Dowel Pin, 3/8 x 1 in.
T15	Drive Gear
T17	Breather, 1/2 NPT
T18	Magnetic Drain Plug, 1/2 NPT
T19	Hex Hd Screw, 3/8-16 x 1-1/4 in.
T24	Oil Seal
T25	Lockwasher, 3/8 in.
T26	Lockwasher, 7/16 in.


REF. NO.	DESCRIPTION
T28	Retaining Ring
T31	Pipe Plug, 1/2 NPT
T32	Drive Screw, No. 6 x 1/4 in.
T33	Ball Bearing
T34	Ball Bearing
T50	Oil Seal
T67	Oil Level Plate
T69	Street Elbow, 45 Degree x 1/2 NPT
T75	Bearing Spacer
T76	Square Key
T77	Castle Nut or Nylok Nut
T79	Flat Washer, 3/4 in.
T80	Cotter Pin, 1/8 x 1-1/2 in.
T87	Adapter Bushing
T88	Hydraulic Motor/Pump Adapter
T90	Hex Head Screw, 7/16-14 x 1 in.
T91	Socket Head Scew, 7/16-14 x 1-1/4 in.
T92	Hex Head Screw, 3/8-16 x 1 in.



### Extended Impeller Shaft 1-1/8 in. Keyed Input Shaft Models: CLVK, CLRK, CLSK, CPK-1, CPK-2

REF. NO.	DESCRIPTION
T1	Woodruff Key
T2	Serial Plate (CPK-1, CPK-2 Models Only)
Т3	Driven Gear
T4	Gasket
T5	Bearing Spacer
Т6	Gasket
T7	Retaining Ring
T8	Gasket
Т9	Bearing Cover
T10	Oil Seal Housing
T11	Drive Shaft
T13	Gear Case Subassembly
T14	Dowel Pin, 3/8 x 1 in.
T15	Drive Gear
T18	Magnetic Drain Plug, 1/2 NPT
T19	Hex Hd Screw, 3/8-16 x 1-1/4 in.
T24	Oil Seal
T25	Lockwasher, 3/8 in.
T28	Retaining Ring
T31	Pipe Plug, 1/2 NPT


REF. NO.	DESCRIPTION
T32	Drive Screw, No. 6 x 1/4 in.
T33	Ball Bearing
T34	Ball Bearing
T50	Oil Seal
T67	Oil Level Plate
T75	Bearing Spacer
T76	Square Key
T77	Castle Nut or Nylok Nut
T79	Flat Washer, 3/4 in.
T80	Cotter Pin, 1/8 x 1-1/2 in.
T92	Hex Head Screw, 3/8-16 x 1 in.
T94	Square Key, 5/16 x 2-15/16 in.
T105	Oil Seal Sleeve
T106	Oil Seal
T107	Square Key, 3/16 x 1 in.
T108	Nylok Nut
T109	Bearing Locknut
T110	Bearing Lockwasher



# Extended Impeller Shaft Hydraulic Pump Adapter Input Shaft Models: CLVK, CLRK, CLSK, CPK-1, CPK-2

REF. NO.	DESCRIPTION
T1	Woodruff Key
T2	Serial Plate (CPK-1, CPK-2 Models Only)
Т3	Driven Gear
T4	Gasket
T5	Bearing Spacer
T6	Gasket
T7	Retaining Ring
Т8	Gasket
Т9	Bearing Cover
T10	Oil Seal Housing
T11	Drive Shaft
T13	Gear Case Subassembly
T14	Dowel Pin, 3/8 x 1 in.
T15	Drive Gear
T17	Breather, 1/2 NPT
T18	Magnetic Drain Plug, 1/2 NPT
T19	Hex Hd Screw, 3/8-16 x 1-1/4 in.
T24	Oil Seal
T25	Lockwasher, 3/8 in.
T28	Retaining Ring
T31	Pipe Plug, 1/2 NPT

REF. NO.	DESCRIPTION
T32	Drive Screw, No. 6 x 1/4 in.
T33	Ball Bearing
T34	Ball Bearing
T50	Oil Seal
T67	Oil Level Plate
T69	Street Elbow, 45 Degree x 1/2 NPT
T75	Bearing Spacer
T76	Square Key
T77	Castle Nut or Nylok Nut
T79	Flat Washer, 3/4 in.
T80	Cotter Pin, 1/8 x 1-1/2 in.
T88	Hydraulic Motor/Pump Adapter
T92	Hex Head Screw, 3/8-16 x 1 in.
T94	Square Key, 5/16 x 2-15/16 in.
T105	Oil Seal Sleeve
T106	Oil Seal
T107	Square Key, 3/16 x 1 in.
T108	Nylok Nut
T109	Bearing Locknut
T110	Bearing Lockwasher




### Non-Extended Impeller Shaft 1-1/8 in. Keyed Input Shaft

Models: CPK-3 (Pumps Built After December 1, 1990)

REF. NO.	DESCRIPTION
T1	Woodruff Key
T2	Serial Plate
Т3	Driven Gear
T4	Gasket
T6	Gasket
T8	Gasket
Т9	Bearing Cover
T10	Oil Seal Housing
T11	Drive Shaft
T13	Gear Case Subassembly
T14	Dowel Pin, 3/8 x 1 in.
T15	Drive Gear
T17	Breather, 1/2 NPT
T18	Magnetic Drain Plug, 1/2 NPT
T19	Hex Hd Screw, 3/8-16 x 1-1/4 in.
T24	Oil Seal


REF. NO.	DESCRIPTION
T25	Lockwasher, 3/8 in.
T28	Retaining Ring
T31	Pipe Plug, 1/2 NPT
T32	Drive Screw, No. 6 x 1/4 in.
T33	Ball Bearing
T34	Ball Bearing
T50	Oil Seal
T67	Oil Level Plate
T69	Street Elbow, 45 Degree x 1/2 NPT
T75	Bearing Spacer
T76	Square Key
T77	Castle Nut or Nylok Nut
T79	Flat Washer, 3/4 in.
T80	Cotter Pin, 1/8 x 1-1/2 in.
T92	Hex Head Screw, 3/8-16 x 1 in.
T93	Driven Shaft



# Combination Pumps Main Pump Models: CM, CMU, CS, CSU, CGG Combination Pump Models: CPK-1, CPK-2

REF. NO.	DESCRIPTION
T1	Woodruff Key
T2	Serial Plate
Т3	Driven Gear
T4	Gasket
T6	Gasket
T8	Gasket
Т9	Bearing Cover
T10	Oil Seal Housing
T11	Drive Shaft
T13	Gear Case Subassembly
T14	Dowel Pin, 3/8 x 1 in.
T15	Drive Gear
T17	Breather, 1/2 NPT
T18	Magnetic Drain Plug, 1/2 NPT
T19	Hex Hd Screw, 3/8-16 x 1-1/4 in.
T23	Hex Nut, 1/2-20
T24	Oil Seal
T25	Lockwasher, 3/8 in.
T26	Lockwasher, 7/16 in.
T27	Lockwasher, 1/2 in.


REF. NO.	DESCRIPTION
T28	Retaining Ring
T31	Pipe Plug, 1/2 NPT
T32	Drive Screw, No. 6 x 1/4 in.
T33	Ball Bearing
T34	Ball Bearing
T50	Oil Seal
T67	Oil Level Plate
T75	Bearing Spacer
T76	Square Key
T77	Castle Nut or Nylok Nut
T79	Flat Washer, 3/4 in.
T80	Cotter Pin, 1/8 x 1-1/2 in.
T84	Pipe Nipple, 1/2 x 2-1/2 in.
T85	Elbow, 90 Degree, 1/2 NPT
T87	Adapter Bushing
T89	Gear Case Adapter
T92	Hex Head Screw, 3/8-16 x 1 in.
T103	Hex Head Screw, 1/2 - 13 x 1-1/4 in.
T104	Stud, 1/2-13 x 4-1/4 in.



### Optional Transmission Input Shaft Tachometer Transmission Case Mounting to Pump

REF. NO.	DESCRIPTION
Т6	Gasket
T13	Gear Case Subassembly
T20	Hex Head Screw, 7/16-14 x 1-1/4 in.
T21	Hex Head Screw, 1/2-13 x 1-1/2 in.
T22	Hex Head Screw, 1/2-20 x 2-3/4 in.
T23	Hex Nut, 1/2-20
T25	Lockwasher, 3/8 in.
T26	Lockwasher, 7/16 in.
T27	Lockwasher, 1/2 in.
T36	Tachometer Gear Assembly

REF. NO.	DESCRIPTION
T40	Tachometer Housing
T43	Tachometer Driven Gear
T44	Tachometer/Speedometer Sleeve
T45	Tachometer/Speedometer Bushing
T56	Suspension Pin
T57	Suspension Pin Bracket
T59	Cotter Pin, 5/16 x 2-1/2 in.
T73	Spirol Pin, 3/16 in.
T74	Tachometer Gear Pilot Ring
T92	Hex Head Screw, 3/8-16 x 1 in.





MEDIUM DUTY K TRANSMISSION SPL81614 WATEROUS COMPANY SOUTH ST. PAUL, MN 55075 PAGE 15 OF 17


### **Transmission Case Mounting Positions**

REF. NO.	DESCRIPTION
T17	Breather, 1/2 NPT
T18	Magnetic Drain Plug, 1/2 NPT
T31	Pipe Plug, 1/2 NPT
T32	Drive Screw, No. 6 x 1/4 in.

REF. NO.	DESCRIPTION
T67	Oil Level Plate
T69	Street Elbow, 45 Degree x 1/2 NPT
T84	Pipe Nipple, 1/2 x 2-1/2 in.
T85	Elbow, 90 Degree, 1/2 NPT







TRANSMISSION CASE MOUNTING POSITIONS

MEDIUM DUTY K TRANSMISSION SPL81614 WATEROUS COMPANY SOUTH ST. PAUL, MN 55075 PAGE 17 OF 17