

Technical Bulletin No. 137

Pumping Disinfectants

Date: May 22, 2020

Effective: May 22, 2020

Due to the COVID-19 pandemic, customers have been inquiring about using disinfectant solutions in Waterous equipment.

Waterous does not recommend pumping disinfectant solution through the equipment. However, if you choose to pump disinfectant solution through the equipment, you must immediately flush the system with clear water to minimize corrosion to the metal components, and degradation to the seals. Never store disinfectant solutions in the equipment. Chlorine based disinfectants solutions are of particular concern due to the corrosive reaction with equipment materials—i.e. iron.

