
Document Number
 Issue Date
 Rev. Date

 SPL82743
 07/31/03
 06/03/20


6 in. Butterfly Valve Service Parts List


For valve and pneumatic actuator repair parts not shown, see METSO website (Jamesbury valves).

Valve Ad	ctuator Type	Components	See Page
		Cables and Panel Components	2
Electric		Manual Override	3
		Valve Body	4
		Rotary Actuator	5
Pne	eumatic	Valve and Actuator	6
		Cables and Panel Components	7
	Indicating	Valve Body	8
Manual		Rotary Actuator	9
	Non-Indicating	Valve and Actuator	10



Ref No.	Description
38	Panel Assembly (prior to November 6, 2006)
39	Wire-Switch Extension
40	Wire-Motor Extension
41	Screw-Machine, Flat Hd, Hex Soc, #6-32 x 3/4 in
42	Nut-Hex, Nylok, #6-32
43	Gasket-Valve
45	Valve and Actuator Subassembly
57	Cable-Extension, Encoder
58	Panel Assembly-Control, Electric (after November 6, 2006)
86	Actuator Subassembly






Valve built prior to November 6, 2006

Electric Valves with Cables and Panel Components

Valve built after November 6, 2006





Manual Override

If manual override is used, attach to shaft on opposite side of motor only.

Ref No.Description34Valve-Body, 6 in Jamesbury35Screw-Hex Hd, 3/8-16 x 3/4 in36Washer-Lock, 3/8 in	
36 Washer-Lock, 3/8 in	
49 Valve Seat and Shaft Repair Kit	
	35
	36
Valve Seat and Shaft Seal Repair Kit	
Pump side	
Panel side	
Failei side	

Electric Valve Body







86
Actuator Subassembly


44 Motor Replacement Kit

> 31 Rotary Encoder Replacement Kit

Encoder Details








Ref No.	Description	
4	Pin-Spring, 3/16 x 1 1/4 in	
15	Pin-Spirol, 1/8 x 3/4 in	
41	Screw-Machine, Flat Hd, Hex Soc, #6-	
43	Gasket-Valve	
45	Manual Butterfly Valve (Includes Actua	or)
51	Shaft-Extension, Handle	
69	LED Panel Assembly	
70	Cable-Extension, Encoder	
82	Handle-Discharge Valve	
86	Actuator Subassembly	
	Actuator Subasserribly	
		43
	USE	43 gasket adhesive when installing
		Pu
		70—
		~ >
	69—	
ground—		
	41	Control panel power wi furnished two ways: - With 3 amp in-line fus - Without 3 amp in-line (Panel 69 has an inter which resets automati
	Part of 69	- With 3 amp in-line fus - Without 3 amp in-line
		(Panel 69 has an interwhich resets automati
		Ĭ


Manual Indicating Valve with Cable and Panel Components

Ref No.	Description
34	Valve-Body, 6 in Jamesbury
35	Screw-Hex Hd, 3/8-16 x 3/4 in
36	Washer-Lock, 3/8 in
49	Valve Seat and Shaft Seal Repair Kit

49 Valve Seat and Shaft Seal Repair Kit



Manual Indicating Valve Body



86
Actuator Subassembly

Ref No.	Description
31	Encoder-Rotary, 90°
86	Actuator Subassembly

Encoder Details

